

INSTALLATION GUIDE

1. Inspect the slabs before application (Thickness, Design, Shades & other Specifications).
2. Keep the quartz slabs away from direct sunlight and with proper support towards the back when storing.
3. Quartz Slabs are for Indoor applications only and not for outdoor application.
4. Make sure the surface of application is in level and proper orientation so that the application process is hassle free.
5. Cutting process is same as of a typical granite cutting i.e. using water cooled power tools and using the same blades which are used for granite.
6. Before cutting take measure of the on field measurements so to prepare the cut sizes that can fit right into the place with minimum joints.
7. Prefer polymer modified adhesives for installation purposes.
8. For Lamination of the joint we recommend Akepox5010 or Marmopoxy Gel. Similar color can be used with the adhesive to match color of the joints.
9. After application of the chemical for lamination proper clamping is required at regular interval to reduce the joint to maximum possible. remove the excessive chemical to give neat look to the joint.
10. After that using diamond pads (for quartz) provide the edges a smooth finish similar to that of the top of the quartz slab.
11. For Flooring/or base of the counter-top we recommend the use of cement based adhesive such as Kerakoll Biofix or Laticrete 252
12. Only For joints (that are vertical joints and applied horizontally) between counter we can use structural silicone or epoxy adhesives
13. Allow 1 millimeter gap for expansion for every 1 meter preferably towards the end of the counter such as under the backsplash or skirting in the case of flooring.